

# LinerGrip Pipeline Rehabilitation Technology

Easy to Install

## Step 1

The polyethylene pipe is cut to length, after ensuring pipe is fully relaxed.

## Step 2

After cutting to length, the centre sleeve is placed over the host pipe, and a coated insert is installed into the polyethylene pipe.

The gripper bracelet, gasket divider and gasket are installed onto the polyethylene pipe end.

## Step 3

The main flange body is installed over the polyethylene pipe, locating the studs into the centre sleeve. This encloses the gasket and gripper. Use of mechanical handling will aid on large diameter products.

## Step 4

The flange body studs are tightened, compressing the gasket and engaging the gripping teeth. The host main end ring is tightened. Installation is now complete.

